



- Turn on the unit by rotating the volume knob.
- Adjusting for Low, Mid or High Gain using toggle switch.
- LED notification :
  - When using the unit :
    - **Blue LED ON** = the battery is OK
    - **Blue LED is OFF** = low battery, but the unit remain ON for a couple minute.
  - When charging the unit :
    - **Red LED ON, Green LED OFF** = Charging process started.
    - **Red LED ON, Green LED ON** = Charging process almost completed.
    - **Red LED OFF, Green LED ON** = Charging process completed